

# **623**

# **Digital Manometer** Instruction Manual



#### **Table of Contents**

- Page 3 Introduction & Product Description
- Page 4 Safety Considerations
- Page 5 Technical Data & International Symbols
- Page 6 Features & Benefits
- Page 7 Pressure Conversion Table
- Page 8 Step by Step Procedures
- Page 10 Accessories & Specifications
- Page 11 Maintenance
- Page 12 Trouble shooting guide
- Page 13 EC declaration of conformity

## Introduction

## **Congratulations**

Thank you for purchasing TPI brand products. This meter is easy to use and is built to last. It is backed by a 2 year limited warranty. Please remember to return your product warranty registration card.

## **Product Description**

The TPI 623 is a hand held pressure meter with superior resolution.

Auto Range -100.0 to -100.0 mbar

-40.0 to 40.0 inH<sub>2</sub>0

Resolution  $0.001 \text{ inH}_2\text{O} / 0.01 \text{ inH}_2\text{O}$ 

Accuracy  $< \pm /-2 \text{ inH}_20: \pm (0.02 \text{ inH}_20)$ 

 $> +/- 2 inH_2O: \pm (1\% of reading)$ 

Over Pressure Protected to 50 inH<sub>2</sub>O

Power Supply 9V

## **Safety Considerations**

WARNING: Please follow the manufacturer's test procedure whenever possible. Make sure the pressure to be measured is not outside the range of the TPI 623 meter.

#### **ALWAYS**

- Test the pressure meter before use to ensure it is operating properly
- Ensure that the connecting hose you are using is free from kinks or splits
- Double check all connections before testing

#### **NEVER**

- Connect the Instrument to an unknown pressure source if the source is twice the working pressure of the instrument the sensor will be damaged and may cause injury to the user
- Tamper with the instrument or attempt to modify it in any way. Otherwise, accident and injury may occur and the warranty becomes void.



## **Technical Data**

#### **Controls**

- Turns the 623 on. Hold down to turn unit off.
- **ZERO** Momentarily press the  $\circlearrowleft$  button to "ZERO" the dispaly ("ZERO" will temporarily display in the lower left of the LCD)
- Smoothing function to stabilize rapidly changing pressure readings
- **UNITS** Selects 7 units of pressure kPa, PSI, inHg, mmHg, inH<sub>2</sub>O, mmH<sub>2</sub>O, mbar
  - Turns the back light on (automatically turns off after 30 seconds)

## **Features & Benefits**

Autoranging - Provides high resolution & accuracy at low

Auto Power Off - Powers off after 40 minutes to conserve battery life.

Trim Mode - Smoothing function to stabilize erratic readings. It displays the average value of 4 values previously measured.

Zero Function - Provides immediate push button zeroing for Speed and accuracy.

Units - Change the display value in any one of the following engineering units. kPa, PSI, inHg, mmHg, inH20, mmH20 and mbar.

Back Light - Provides easy reading of LCD in low light areas.

## **Pressure Coverstion Table**

	Atmos	bar	inHg	inH <sub>2</sub> O	PSI	mmHg	mmH <sub>2</sub> 0	Pascals
Atmos	1	9.86923 x 10 <sup>-1</sup>	3.34207 x 10 <sup>-2</sup>	2.458 x 10 <sup>-3</sup>	6.8046 x 10 <sup>-2</sup>	1.316 x 10 <sup>-3</sup>	0.9677 x 10 <sup>-4</sup>	9.869 x 10 <sup>-6</sup>
bar	1.01325	1	3.3864 x 10 <sup>-2</sup>	2.491 x 10 <sup>-3</sup>	6.8948 x 10 <sup>-2</sup>	1.333 x 10 <sup>-3</sup>	0.9807 x 10 <sup>-4</sup>	1.000 x 10 <sup>-5</sup>
inHg	29.9213	29.53	1	7.355 x 10 <sup>-2</sup>	2.036	3.937 x 10 <sup>-2</sup>	2.89567 x 10 <sup>-3</sup>	2.953 x 10 <sup>-4</sup>
inH <sub>2</sub> O	406.8	401.48	13.60	1	27.68	0.5354	3.937 x 10 <sup>-2</sup>	4.014 x 10 <sup>-3</sup>
PSI	14.6955	14.504	0.4912	3.6127 x 10 <sup>-2</sup>	1	1.934 x 10 <sup>-2</sup>	1.422323 x 10 <sup>-3</sup>	1.4503 x 10 <sup>-3</sup>
mmHg	760	750.06	25.400	1.868	51.715	1	7.35433 x 10 <sup>-2</sup>	7.502 x 10 <sup>-3</sup>
mmH <sub>2</sub> O	10.3327 x 10 <sup>3</sup>	10.1976 x 10 <sup>3</sup>	3.4544 x 10 <sup>2</sup>	25.400	703.07	13.599	1	.101972
Pascals	1.01325 x 10 <sup>5</sup>	1.000 x 10 <sup>5</sup>	3.386 x 10 <sup>3</sup>	2.491 x 10 <sup>2</sup>	6.8948 x 10 <sup>3</sup>	1.333 x 10 <sup>2</sup>	9.8071	1

## **Step by Step Procedures**

#### Note:

The 623 incorporates a differential manometer. This means when a single hose is connected to the (+) port and pressure is applied, the 623 will read positive pressure. If a single hose is connected to the (-) port and pressure is applied, the 623 will read a negative pressure. If both ports are connected to a pressure, the 623 will read the difference (P1 - P2) between the two.

When performing single pressure measurments (non-differential) use the positive port and leave the negative port open.

## **Step by Step Procedures (continued)**

- 1. Press the 'ON' key and the LCD display will be activated and automatically zeroed (if it does not read 0.00 proceed as follows
- 2. Momentarily Press the Ukey and the display should zero within +/- 0.01 if not repeat until it does
- 3. Connect pressure meter to installation or equipment to be tested using appropriate hose connection in accordance with the manufacturers instructions
- 4. The pressure reading will appear on the display. To activate the backlight in poor light conditions press the \*key at any time
- 5. If the reading is erratic or changing activate the smoothing function by pressing the '=' key
- 6. To convert the displayed pressure reading to another engineering unit depress the 'UNIT' key anytime and scroll through to the desired units of pressure.

# **Accessories & Specifications**

#### Standard accessories

9V battery
Soft Pouch
Protective boot with magnets A6XX
Silicone tubing w/ 1/4" barbed
1/8" NPT fitting

## **Specifications**

Auto Range -100.0 to -100.0 mbar

-40.0 to 40.0 inH<sub>2</sub>0

Resolution  $0.001 \text{ inH}_2\text{O} / 0.01 \text{ inH}_2\text{O}$ 

Accuracy  $< +/-2 \text{ inH}_20: \pm (0.02 \text{ inH}_20)$ 

 $> +/- 2 inH_2O: \pm (1\% of reading)$ 

Over Pressure Protected to 50 in H<sub>2</sub>O

Power Supply 9V

Relative Humidity 0% to 80%

Operating Temp. 0°C to +40°C

Storage Temp. -10°C to +50°C

Auto Power Off 20 Minutes

Input Type Differential



#### **Maintenance**

## **Battery Replacement:**

The 623 will display a battery symbol when the internal 9V battery needs replacement. Replace battery as follows:

- 1. Ensure instrument is switched off
- 2. Loosen the six cross head screws on the back of the instrument
- 3. Remove the back cover
- 4. Remove old battery
- 5. Replace with new battery 9V NEDA 1604 or equivalent
- 6. Reassemble the instrument in reverse order from above being sure not to trap any wires between the two halves of the case
- 7. Re-fit the six cross head screws being sure not to over tighten

**Cleaning:** Use a mild detergent and a slightly damp cloth to clean the surfaces of the instrument.

## **Trouble Shooting Guide**

Problem	Probable Cause
Unit does not zero	Zero button has not been pushed.
Unit still does not zero	If reading is greater than 0.05 and constantly fluctuates return to local
'Bat' appears on display	Service Centre. Replace battery immediately 9V NEDA 1505 or equivalent

## **EC Declaration of Conformity**

This is to certify that model 623 conforms to the protection requirements of the council directive 89/336/EEC, in the approximation of laws of the member states relating to Electromagnetic compatibility by application of the following standards EN50081-1 1992 Emissions Standard EN50082-1 1992 Immunity Standard

To ensure conformity with these standards, this instrument must be operated in accordance with the instructions and specifications given in this manual.