



Series UFB Ultrasonic Flowmeter Kit
Installation and Operating Instructions





Table of Contents

1: General Description	1
1.1 Introduction	1
1.2 Principles of Operation	2
1.3 Supplied Hardware	3
1.4 UFB Instrument	4
1.4.1 Connections	4
1.4.2 Keypad	4
1.4.3 Power supply	5
2: Installation	6
2.1 Safety Precautions and Warnings	6
2.2 Installing the UFB Instrument	6
2.2.1 Positioning the instrument	6
2.2.2 Mounting the instrument	7
2.2.3 Connecting the instrument	8
2.3 Installing the Ultrasonic Transducers	9
2.3.1 Transducer positioning	9
2.3.2 Transducer attachment	10
2.3.3 Attaching the guide rail to the pipe	11
2.3.4 Fitting the transducers	11
2.3.5 Transducer attachment (diagonal mode)	14
3: Operating Procedures	16
3.1 Setting-up the Instrument	17
3.1.1 Using the instrument for the first time	17
3.1.2 Changing the user language	17
3.2 Using the Quick Start Menu	18
3.3 Instrument Calibration	22
3.3.1 Adjusting the zero cut-off	22
3.3.2 Adjusting the set zero flow offset	22
3.3.3 Adjusting the calibration factor	23
3.3.4 Adjusting the roughness factor	24
3.3.5 Adjusting the damping factor	24
3.4 Outputs	26
3.4.1 Current output	26
3.4.2 Pulse output	28
3.4.3 Alarm outputs	29



3.5	How to Measure Totalized Flows (manually)	32
3.6	Display of totalizers	33
3.7	Setting the Chiller Options	33
3.7.1	Setting the Chiller Delay	34
3.8	Operation with an Energy Meter	35
3.8.1	Pulse output	35
3.8.2	Configuring the UFB	35
4:	Maintenance & Repair	37
4.1	Introduction	37
4.2	General care	37
4.3	Warranty / Return	37
5:	Troubleshooting	38
5.1	Overview	38
5.2	General Troubleshooting Procedure	39
5.3	Warning and Status Messages	40
5.4	Diagnostics Display	42
6:	Options	43
6.1	Large Pipe Diameter Transducers	43
6.2	Transducer Holder Options	43
6.3	Extended Signal Cable Options	43
7:	Specification	44

1: *General Description*

1.1 Introduction

This manual describes the operation of the UFB flowmeter. The flowmeter is designed to work with clamp-on transducers to enable the flow of a liquid within a closed pipe to be measured accurately without needing to insert any mechanical parts through the pipe wall or protrude into the flow system.

Using ultrasonic *transit time* techniques, the UFB is controlled by a micro-processor system which contains a wide range of data that enables it to be used with pipes having an outside diameter ranging from 0.5 to 79 inches (13 to 2000 mm) and constructed of almost any material. This can be extended to pipes of up to 197 inches (5000 mm) using the optional type D sensors. The instrument will also operate over a wide range of fluid temperatures.

UFB standard features:

- Large, easy to read graphic display with backlight.
- Simple to follow, dual function keypad.
- Simple 'Quick Start' set up procedure.
- Continuous signal monitoring.
- Isolated pulse output (volumetric or frequency).
- Isolated current output (4 to 20 mA, 0 to 20 mA, or 0 to 16 mA).
- 2x Isolated programmable alarm outputs.
- Password-protected menu operation for secure use.
- Signal diagnostics.
- Multi-function alarm outputs.
- Operates from Mains, 24 Vac, or 24 Vdc.

Volumetric flow rates are displayed in L/h, L/min, L/sec, gal/min, gal/h, USgals/min, USgals/h, Barrel/h, Barrel/day, m³/s, m³/min, m³/h. Linear velocity is displayed in meters or feet per second. When operating in the 'Flow Reading' mode the total volumes, both positive and negative, are displayed up to a maximum 12-digit number.

The flowmeter can be used to measure clean liquids or oils that have less than 3% by volume of particulate content. Cloudy liquids such as river water and effluent can be measured along with cleaner liquids such as demineralized water.

Typical UFB applications include:

- Sea or River water.
- Potable water.
- Demineralized water.
- Treated water.

The UFB is available in two model options. Model UFB-A is supplied with type 'A' transducers which are designed to work with pipe diameters between 0.5 to 4.5 inches (13 to 115 mm). Model UFB-B is supplied with type 'B' transducers which are designed to work with pipe diameters between 2 to 79 inches (50 to 2000 mm). Both sets of transducers use a common mounting system for pipe attachment, and throughout this manual any reference to 'UFB' applies to both 'A' and 'B' model variants unless otherwise stated.

Note: In addition to the 'A' and 'B' type sensors, type 'D' sensors (option) are available for use on pipes up to 197 inches (5000 mm). These sensors have a different mounting method. See Paragraph 1.3 for further details.

1.2 Principles of Operation




Figure 1.1 Operating modes

When ultrasound is transmitted through a liquid, the speed at which the sound travels through the liquid is accelerated slightly if it is transmitted in the same direction as the liquid flow, and decelerated slightly if transmitted against it. The difference in time taken by the sound to travel the same distance but in opposite directions is therefore directly proportional to the flow velocity of the liquid.

The UFB system employs two ultrasonic transducers attached to the pipe carrying the liquid and compares the time taken to transmit an ultrasound signal in each direction. If the sound characteristics of the fluid are known, the instrument's microprocessor can use the results of the transit time calculations to compute the fluid flow velocity. Once the flow velocity is known the volumetric flow can be easily calculated for a given pipe diameter.



The system can be set up to operate in one of four modes, determined mainly by the pipe diameter and the type of transducer set in use. The diagram in Figure 1.1 illustrates the importance of applying the correct separation distance between the transducers to obtain the strongest, and therefore most reliable, signal.

1.3 Supplied Hardware

The supplied UFB components are shown in Figure 1.2.



Figure 1.2 Standard UFB equipment

UFB Standard equipment

- Instrument with backlit graphic display.
- Transducer cables (x2) 16.5 feet (5.0m) in length.
- Transducers 'A-ST' x2 (UFB-A) for use with pipes ranging 0.5 to 4.5 inches (13 to 115 mm).
- Transducers 'B-ST' x2 (UFB-B) for use with pipes ranging 2 to 79 Inches (50 to 2000 mm).
- Transducer holder for use with 'A' or 'B' transducers.
- Steel bands used to secure the transducer holder to the pipe.
- Acoustic couplant.
- User documentation.

UFB Optional equipment

- Transducer set 'D' can be used for monitoring pipes of 59 inches to 197 inches (1500 to 5000 mm) outside diameter, over a temperature range -4°F to +176°F (-20°C to +80°C). This optional kit is supplied in a separate case and includes the type 'D' transducers together with ratchet straps and holders for attaching the transducers to the pipe.



1.4 UFB Instrument

The UFB is a microprocessor controlled instrument operated through a menu system using an inbuilt LCD display and keypad. It can be used to display the instantaneous fluid flow rate or velocity, together with totalized volumes. The instrument also provides an isolated current output, or variable pulse output, that is proportional to the measured flow rate and can be scaled to suit a particular flow range. Two isolated alarm outputs are provided which can be configured in a number of ways. For example, to operate when the flow rate exceeds a specified maximum or minimum value.




Figure 1.3 Instrument details

1.4.1 Connections

Transducer connections

The transducers are connected to two coaxial sockets located on the bottom left-hand of the instrument. The silk-screen above these connectors show a red and blue triangle and a direction of flow symbol. For a positive flow reading, it is important that the upstream transducer is connected to the RED socket and the downstream transducer to the BLUE one. It is safe to connect or disconnect these cables while the instrument is switched on.

4 to 20 mA, 'Pulse', and Alarm I/O connections

The 4 to 20 mA, 'pulse', and alarm I/O cables, enter the bottom of the instrument via two cable glands and connected internally to a terminal block. Full details of the terminal connections are provided in Chapter 2 (Installation).

Power supply

Two cable glands located on the bottom right-hand side of the instrument are available for the power supply cable. Two sizes of glands are provided to accept cables of different diameters.

1.4.2 Keypad

The instrument is configured and controlled via a 15-key tactile membrane keypad, as shown in Figure 1.4.



1: General Description




Figure 1.4 UFB Keypad

Menus and the menu selection keys

Note: As a security measure, once the instrument has been set-up for the first time, a password is required to gain subsequent access to the operating menus (see page 20).

The UFB menus are arranged hierarchically with the MAIN MENU being at the top level. Menu navigation is achieved by three keys located on the right hand side of the keypad which are used to scroll UP and DOWN a menu list and SELECT a menu item. When scrolling through a menu, an arrow-shaped cursor moves up and down the left hand side of the screen to indicate the active menu choice which can then be selected by pressing the ENTER (SELECT) key.

Some menus have more options than can be shown on the screen at the same time, in which case the overflowed choices can be brought into view by continuing to scroll DOWN past the bottom visible item. Menus generally 'loop around' if you scroll beyond the first or last items.

If you select Exit on any menu it usually takes you back one level in the menu hierarchy, but in some cases it may go directly to the 'Flow Reading' screen.

Some screens require you to move the cursor left and right along the display as well as up and down. This is achieved using keys 5 (scroll LEFT) and 6 (scroll RIGHT).

Dual function numerical keypad

The block of keys shown in the center of the keypad in Figure 1.4 are dual function keys. They can be used to enter straight-forward numerical data, select the displayed flow units, or provide quick access to frequently required control menus.

1.4.3 Power supply

Mains supply

As standard, the UFB instrument is designed to work with a mains supply of 86 to 236 Vac and 50/60 Hz. A mains supply fuse is located adjacent to the mains power connection (see Figure 2.2).

24V Supply

An alternative 24 V (ac/dc) power supply module is available as a factory fitted option.

Power failure

The instrument will automatically power-up and become operational when the input power is applied. In the event of a power failure, the instrument's configuration parameters are stored in non-volatile memory which then allows the instrument to return to normal operation immediately power is restored.



2: Installation

2.1 Safety Precautions and Warnings



WARNING

LETHAL VOLTAGES

You may be exposed to potentially lethal (mains) voltages when the terminal cover of this instrument is removed. Always isolate the supply to this instrument before removing the terminal cover.



WARNING

LETHAL VOLTAGES

This instrument must be installed by an electrically qualified technician aware of the potential shock hazards presented when working with mains powered equipment.



WARNING

SUPPLY EARTHING

If the equipment is powered from a 24 Vac supply then the supply must be isolated from earth.



Caution

IP65 Enclosure Protection

Blanking plugs are fitted to the cable glands on leaving the manufacturer. In order to preserve the enclosure's IP65 rating, ensure that the blanking plugs remain fitted in any unused cable gland.

2.2 Installing the UFB Instrument

2.2.1 Positioning the instrument

The UFB instrument should be installed as close as conveniently possible to the pipe-mounted ultrasonic sensors. Standard transducer cables are 16.5 ft (5 m) in length with 33 ft (10 m) cables being optionally available. Where, for operational reasons, it is not possible to mount the instrument this close to the sensors, bespoke cables of up to 328 ft (100 m) can be provided. Consult Dwyer for further information and availability.

A suitable mains supply must be available to power the instrument (an optional 24V (ac/dc) supply module is available). The external supply must be suitably protected and connected via an identifiable isolator. A 500 mA fuse is fitted internally in the instrument's input supply line.



2.2.2 Mounting the instrument

Ideally, the UFB enclosure should be fixed to a wall using three screws – see Figure 2.2.

1. Remove the UFB terminal cover.
2. Fix a screw into the wall at the required point to align with the mounting keyhole on the back of the enclosure.
3. Attach the enclosure to the wall using the keyhole screw mounting.
4. Align the enclosure then mark out the positions for the two remaining screw fixings through the slots near the bottom corners of the enclosure. Then remove the enclosure, and drill (and plug) the two fixing points.
5. Clear the site of any dust/debris, then mount the enclosure on the wall.




Figure 2.1 UFB Mounting and connection details



2.2.3 Connecting the instrument

All cables enter the instrument through the (4) cable glands and then connected to terminal blocks which are located behind a safety cover. The terminal blocks use a spring-loaded securing mechanism which is opened by lifting the orange tab situated on the top of the terminal connection.

Control & monitoring cables

Depending on the fitted options, any of the following control and monitoring cables may be required:

- *Current output* – a 4 to 20 mA, 0 to 16 mA, or 0 to 20 mA monitoring signal is output at terminal mA+ and mA- . (mA+ is the current output terminal and mA- is the return terminal).
 - *Pulse output* – an opto-isolated pulse output is available at terminals PULSE+ and PULSE- (PULSE+ is the pulse output terminal and PULSE- is the return terminal).
 - *Alarm Outputs* – two programmable, multifunction alarm outputs are available using MOSFET, SPNO relays. The relays, which are rated at 48 V/500 mA continuous load, are connected to terminals ALARM1+, ALARM1-, ALARM2+ and ALARM2- respectively.
1. Remove the terminal block cover.
 2. Route the control and monitoring cables through the two smaller cable glands.
 3. Cut the wires to length, strip back the insulation by approximately 0.4in (10 mm) and connect them to the required terminals identified in Figure 2.1.
 4. On completion, tighten the cable glands to ensure the cables are held securely.

Power connections



LETHAL VOLTAGES

**Ensure the power cable is isolated from the mains supply.
Do not apply mains voltage with the terminal cover removed.**



SUPPLY EARTHING

**If the equipment is powered from a 24V AC supply then the
supply must be isolated from earth.**

The UFB instrument can be powered from a mains supply (86 to 264 Vac, 47 to 63 Hz) or from a 24 V(ac/dc) supply if it is fitted with a 24 V supply module.

1. Route the power cable through one of the two cable glands located below the power connection terminals, using the gland most suitable for the power cable diameter.
2. Cut the wires to length, strip back the insulation by approximately 0.4 inches (10mm), and connected to them to the correct power supply terminals identified in Figure 2.1.
3. On completion, tighten the cable glands to ensure the cables are held securely.
4. Refit the terminal block cover.

2.3 Installing the Ultrasonic Transducers

2.3.1 Transducer positioning

The UFB equipment expects a uniform flow profile as a distorted flow will produce unpredictable measurement errors. Flow profile distortions can result from upstream disturbances such as bends, tees, valves, pumps and other similar obstructions.





Figure 2.2 Locating the transducers

In many applications an even flow velocity profile over a full 360° is unattainable due to, for example, air turbulence at the top of the flow and possibly sludge in the bottom of the pipe. Experience has shown that the most consistently accurate results are achieved when the transducer holders are mounted at 45° with respect to the top of the pipe.



***Note:** when using the UFB in the 'diagonal' mode an additional transducer holder and fixing kit is required.

Figure 2.3 Transducer holder attachment (reflex vs. diagonal mode)

To obtain the most accurate results, the condition of both the liquid and the pipe wall must be suitable to allow the ultrasound transmission along its predetermined path. It is important also that the liquid flows uniformly within the length of pipe being monitored and that the flow profile is not distorted by any upstream or downstream obstructions. This is best achieved by ensuring there is a straight length of pipe upstream of the transducers of at least 20 times the pipe diameter and 10 times the pipe diameter on the downstream side, as shown in Figure 2.2. Flow measurements can be made on shorter lengths of straight pipe, down to 10 diameters upstream and 5 diameters downstream, but when the transducers are positioned this close to any obstruction the resulting errors can be unpredictable.



Key Point: Do not expect to obtain accurate results if the transducers are positioned close to any obstructions that distort the uniformity of the flow profile.

Preparation

Before you attach the transducers you should first ensure that the proposed location satisfies the distance requirements shown in Figure 2.2, otherwise the resulting accuracy of the flow readings may be affected.

Prepare the pipe by degreasing it and removing any loose material or flaking paint in order to obtain the best possible surface. A smooth contact between the pipe surface and the face of the transducers is an important factor in achieving a good ultrasound signal strength, and therefore maximum accuracy.

2.3.2 Transducer attachment




Figure 2.4 Transducer attachment (completed assembly)

Type 'A' or 'B' transducers are attached to the pipe using the adjustable guide rail assembly shown in Figure 2.4. The guide rail itself is secured to the pipe using two wrap-around steel bands. For user convenience, an imperial (inches) and metric (millimetres) ruler is attached to the side plate of the guide rail – as shown in Figure 2.4. Once the guide rail assembly is fully assembled the transducers are locked into position by tightening the transducer clamp.

Note: When using the UFB in the 'diagonal' mode, or in 'reflex' mode on pipes over 13.75 inches diameter, two guide rails are required with a transducer mounted in each one – see Paragraph 2.3.5 for diagonal mode details.

2.3.3 Attaching the guide rail to the pipe

1. Position the guide rail horizontally on the pipe at 45° with respect to the top of the pipe and secure it in position using the supplied stainless steel banding, as shown in Figure 2.5.

Note: In the following procedure the guide rail is installed with the rectangular opening facing towards the upstream end of the pipe.



Figure 2.5

2.3.4 Fitting the transducers

1. Tighten each transducer clamp clockwise until it is close to the top of the transducer Figure 2.6. This is necessary in order to prevent the acoustic couplant touching the pipe when the transducer is initially inserted into the guide rail – as described below.
2. Using the supplied syringe applicator, apply a 0.1 inch bead of acoustic couplant to the base of both transducers (Figure 2.7).



Figure 2.6



Figure 2.7

3. Thread the downstream transducer cable (blue) through the right-hand end of the guide rail and up through the rectangular opening at the top left-hand end of the guide rail, as shown in Figure 2.8.
4. Connect the downstream cable (blue) to one of the transducers.




Figure 2.8

Note: When carrying out the following steps handle the transducer assembly with care to avoid smearing the acoustic couplant on the pipe whilst attaching the transducer to the guide rail.

5. Carefully lower the transducer and cable through the rectangular opening until the slots in the side of the transducer clamp align with the edges on the top of the guide rail.




Figure 2.9

6. Carefully slide the downstream transducer assembly along the guide rail until the inner face of the transducer is aligned with the '0' mark on the ruler scale (Figure 2.10).
7. Lower the transducer onto the pipe by turning the transducer clamp anti-clockwise until it is 'finger tight' (do not use a spanner).




Figure 2.10

8. Thread the upstream signal cable (red) through the left-hand end of the mounting rail and connect it to the second transducer (Figure 2.11).
9. Following the method used to insert the downstream transducer, carefully lower the downstream assembly through the rectangular opening until the slots in the side of the transducer clamp align with the edges on the top of the guide rail (Figure 2.9).



Figure 2.11

10. Position the upstream transducer so that the inner face of the transducer is set to the required separation distance on the ruler, as shown in Figure 2.12 (2 inches in this example).

Note: The separation distance for a particular application can be found using the 'Quickstart' menu as described in Paragraph 3.2.




Figure 2.12

11. Lower the transducer onto the pipe by turning the transducer clamp anti-clockwise until it is 'finger tight' (do not use a spanner).

Figure 2.13 shows the final position of the transducers when the transducer clamps are fully tightened.

12. Ensure the transducer signal cables are correctly connected to the UFB instrument – i.e. with the RED cable connected to the upstream transducer connector and the BLUE cable to the downstream transducer connector.




Figure 2.13

13. In some cases, particularly on large pipes using diagonal mode, or pipes with a poor internal condition, the signal from the sensors can be very noisy. In order to improve sensor performance and noise immunity, we recommend that the transducers are earthed, using the supplied cables and attachment hardware, in all installations – as shown in Figure 2.14.

Note: Remove any paint on the pipe in the area of the clamp to achieve a good electrical connection.




Figure 2.14



2.3.5 Transducer attachment (diagonal mode)

This mode of operation requires two transducer holders fitted on opposite sides of the pipe, as shown in Figure 2.15 – notice that the transducer holders are still fitted on a 45° axis with respect to the top of the pipe. When used with type 'A' or 'B' transducers, the transducer holders used are identical to that shown above, and the second transducer holder and fixings must be purchased as an option kit.



Key Point: For installations on larger pipes (in the range 79 inches to 197 inches O.D.) it is necessary to use the type 'D' transducer kit which contains the transducers together with their particular mounting rails and fitting instructions. This will have been supplied with the electronics assembly that is configured to work with these larger pipes.

When installing the equipment to operate in the diagonal mode, the method of securing the transducers to the transducer holders and connecting them to the UFB instrument is identical to that described above for the reflex mode. The major difference is that you have to physically mark out the required position of the transducers on the pipe in order to determine where to attach the transducer holders.

1. Obtain and note the required separation distance between the transducers using the 'Quickstart' menu, as described in Paragraph 3.2.
2. Using whatever means available, mark a reference line around the circumference of the pipe approximately where the upstream transducer is to be fitted – line 'A' in Figure 2.15.
3. On line 'A', mark a position (point 'X') on an axis of approximately 45° from the top of the pipe, then draw a three foot line ('B') perpendicular to 'A' and parallel to the pipe axis.
4. On line A, mark a position (point 'Y') 180° opposite point 'X'.
5. From point 'Y', draw a three foot long line ('C') perpendicular to 'A' and parallel to the pipe axis. This is shown as a dashed line in Figure 2.15 as it is on the rear of the pipe.
6. Mark a position (point 'Z') on line 'C' which is equal to the transducer separation distance noted in step 1 from point 'Y'.
7. Position and attach the upstream transducer holder to the pipe such that line 'B' runs centrally along the length of the transducer holder and point 'X' is within the transducer attachment part of the transducer holder.
8. Fit the upstream transducer (red cable) to the transducer holder as described in Paragraph 2.3.4 such that the leading face of the transducer aligns with line 'A'.
9. Position and attach the downstream transducer holder to the pipe such that line 'C' runs centrally along the length of the transducer holder and point 'Z' is within the transducer attachment part of the holder.
10. Fit the downstream transducer (blue cable) to the transducer holder as described in Paragraph 2.3.4 such that the leading face of the transducer aligns with point 'Z'.
11. Connect the transducer cables to the UFB instrument.





Figure 2.15 Transducer mounting for diagonal mode of operation



3: Operating Procedures





3.1 Setting-up the Instrument



Key Point: When the instrument used for the first time the operator has free access to all the set-up and operating menus until the instrument is put into FLOW READING operation, where-upon all the menus become password protected (see page 20).

3.1.1 Using the instrument for the first time

Initial user language selection


The first time you power-up the instrument you will be asked to select a user language, which will then be the default language when the instrument is next used. If you want to change the language when the instrument is in use, see below.

1. On initial power-up, the start-up screen will be displayed for 5 seconds, showing the instrument's serial number and software revision.
2. After 5 seconds, the available language list will be displayed.
3. Select the required language and press ENTER.
4. The instrument will display the MAIN MENU.



The MAIN MENU screen

The MAIN MENU screen is at the top of the menu hierarchy and is the starting point for all the operations described in this chapter. This screen is normally accessed from the FLOW READING screen by pressing the ENTER key.




Note: If you make a mistake when entering the data press the Delete key to move the cursor back to the number you wish to change, then continue. If you enter an invalid number an 'ERR:Invalid Date or Time!' error message is displayed on the second line of the screen. If this occurs repeat the set date/time procedure.

3.1.2 Changing the user language

If you want to change the user language at any time after the instrument has been put into operation:

1. Select Setup Instrument from the MAIN MENU then press ENTER.
2. Select Change Language from the SETUP INSTRUMENT screen then press ENTER.
3. Select the required language from the list provided and press ENTER.
4. The instrument returns to the MAIN MENU.





3.2 Using the Quick Start Menu

The Quick Start menu gathers various data for the site to be monitored and returns details of the transducer configuration that must be applied when mounting the transducers on the pipe.

Before you can use the UFB system you need to obtain the following details (this information is required when setting up the Quick Start menu):

- The pipe outside diameter.
- The pipe wall thickness and material.
- The pipe lining thickness and material (if any).
- The type of fluid contained in the pipe being monitored.
- The fluid temperature.

Entering the site data

1. Select Quick Start from the MAIN MENU and press ENTER. You will then be presented with a series of screens in which to enter the data mentioned above.

2. Select the dimension units (millimeters or inches) used to measure the pipe, then press ENTER.

DIMENSION UNIT	*	*
Select the dimension units:		
mm		
➔Inches		

3. Enter the pipe outside diameter dimension, then press ENTER.

OUTSIDE DIAMETER	*	*
Dimensions:		Inches
Pipe outside diameter:		6.50

4. Enter the pipe wall thickness dimension, then press ENTER.

PIPE WALL THICKNESS	*	*
Dimensions:		Inches
Pipe outside diameter:		6.50
Pipe wall thickness:		0.50

5. If the pipe has a lining, enter the lining thickness.
If nothing is entered the instrument automatically assumes there is no lining.
6. Press ENTER to continue.

PIPE LINING THICKNESS	*	*
Dimensions:		Inches
Pipe outside diameter:		6.50
Pipe wall thickness:		0.50
Pipe lining thickness:		0.12



3: Operating Procedures

7. Select the pipe wall material from the list provided, then press ENTER.

If the material is not listed select Other and enter the propagation rate of the pipe wall material in meters/sec. Contact Dwyer if this is not known.

PIPE WALL MATERIAL	*	*
Select pipe wall material		
Mild Steel		
S' less Steel 316		
S' less Steel 303		
Plastic		
Cast Iron		
Ductile Iron		
Copper		
Brass		
Concrete		
Glass		
Other (m/s)		

8. If a lining thickness value was entered earlier, this screen is displayed to request that you enter the lining material type. If no lining thickness was entered this screen will be bypassed.

9. Select the lining material from the list provided then press ENTER.

If the material is not listed select Other and enter the propagation rate of the lining material in meters/sec. Contact Dwyer if this is not known

PIPE LINING MATERIAL	*	*
Select pipe lining material		
Steel		
Rubber		
Glass		
Epoxy		
Concrete		
Other (m/s)		

10. Select the fluid type from the list provided and press ENTER.

If the liquid is not listed select Other and enter a propagation rate in meters/second. Contact Dwyer if this is not known

FLUID TYPE	*	*
Select fluid type		
Water		
Glycol/water 50%		
Glycol/water 30%		
Lubricating oil		
Diesel		
Freon		
Other (m/s) --		

11. If you need to alter the fluid temperature from that shown select either °C or °F with the cursor and press the ENTER key.

12. Enter the new temperature value and press the ENTER key.

13. The new temperature should now be indicated in both °C and °F.

14. Select Continue.. and press ENTER.

FLUID TEMPERATURE	*	*
Enter Fluid Temperature		
°C: 5.00		
°F: 41.00		
Continue..		



15. The SENSOR SEPARATION screen now displays a summary of the entered parameters and informs you of the type of sensor to be used, the mode of operation, and the distance to set up between the sensors. In this example, it recommends type A-ST (A standard) sensors operating in the 'Reflex' mode spaced at 3.62 Inches apart. Take a note of these details.

SENSOR SEPARATION		*	*
Site	:	Quickstart	
Pipe	:	6.50 Inches	
Wall	:	0.50 Inches	
Sensors	:	A-ST	Reflex
Temperature	:	5.00°C	41.00°F
Set sensor separation to		3.62 Inches	
Press ← to continue, Δ▽ to select sens.			



Key Point: The above example shows the spacing required using a standard type 'A' probe set (A-ST), as supplied with the model UFB-A.

Selecting the operating mode

On large pipes using either type 'B' or 'D' sensors it may be necessary to use the 'Diagonal' mode of operation rather than the 'Reflex' mode. The system will automatically select 'Reflex' mode if it is valid, but the mode can be changed using the following steps.

16. When in the SENSOR SEPARATION screen, press either the Up or Down arrow keys. This will display the SENSOR SELECTION menu.
17. Scroll down to Sensor mode and press ENTER.
18. Scroll to the required mode and press ENTER.
19. Select Exit and press ENTER, to return to the SENSOR SEPARATION screen.
20. The correct sensor separation distance for the selected mode will now be displayed.

Note: Do not press ENTER (to continue with the operating procedure) until the transducers are fitted and connected to the instrument.

Password Control

After data has been entered for the first time, the UFB password control feature is 'enabled' when you exit from Quick start to the FLOW READING screen. This prevents unauthorized tampering of the set-up data. Once 'enabled', a password control box is displayed if any key is pressed and you must then enter 71360 to 'disable' the password control and gain access to any of the menus.

Note: Once disabled, the password control feature is re-enabled if no keys are pressed for five minutes.

Attaching and connecting the transducers

21. Fit the designated sensors to the pipe using the transducer holder as described in Paragraph 2.3.2. The separation distance must be set to within ± 0.02 inches.



Taking a flow reading

22. Once the transducers have been fitted and connected, press the ENTER key twice.
23. This will take you from the SENSOR SEPARATION screen to the FLOW READING screen via the signal-checking screen (shown here).
24. Check that the indicated signal strength on the left of the screen shows at least 2 bars (ideally 3 or 4). If less than 2 bars are shown it indicates there could be a problem with the transducer spacing, alignment or connections; or an application problem.
25. Qxx.xx% indicates the signal quality and should have a value of 60% or greater.

```
Please wait..
Checking signals

*****
*                                           *
*****
```

```
FLOW READING          *           *
Signal                Qxx.xx%
[Signal Bars]      0.000      gal/min
+Total: 0.00        gallons
-Total: 0.00        gallons
```

Flow monitoring

The FLOW READING screen is the one most used during normal monitoring operation. It shows the instantaneous fluid flow together with totalized values (when enabled). In this mode you can select the flow rate measurement units by pressing keys 7 (liters), 8 (Gallons, Barrels) or 9 (m³), or change the display to show velocity by pressing key 4.

If the flow reading exceeds a value of +/-9999 in the current units, then a *10 multiplier will be displayed above the units and the value displayed will be a tenth of the actual value. Similarly a * 100 and *1000 may be displayed on very large flow rates.

Once a valid flow reading is obtained, if the pipe conditions change (such that the flow reading is lost) then the system will automatically rescan to re-establish a stable flow reading. It is important that the instrument is left with the FLOW READING screen on the display because the automatic rescan is disabled if any of the other screens that can be reached from the FLOW READING screen are being displayed.

Note: There will be a delay in the keyboard response if a rescan is in progress when a key is pressed.



3.3 Instrument Calibration

The instrument is fully calibrated before it leaves the factory; however the following adjustments are provided to allow you to further 'fine tune' your instrument to suit local conditions and applications where necessary. Apart from the 'zero flow offset', these adjustments are normally carried out only where the instrument is to be used at a permanent, or semi-permanent, location.

3.3.1 Adjusting the zero cut-off

This adjustment allows you to set a minimum flow rate (m/s) below which the instrument will indicate '0'. The default setting is 0.1 m/s but you may adjust this value if required.

1. With the instrument operating in FLOW READING mode, press the Options key to access the FLOW READING OPTIONS menu shown (password required).
2. Select Zero Cutoff (m/s) and press ENTER.
3. Enter the value for the Zero Cutoff (e.g. 0.06 m/s) then press ENTER.
4. Scroll down to select Exit and press ENTER to return to the FLOW READING screen.

FLOW READING OPTION	*	*
Data review		
Zero Cutoff (m/s)	:	0.100
Set zero flow (m/s)	:	0.000
Damping (secs)	:	10
Totalizer	:	Run
Reset +Total		

3.3.2 Adjusting the set zero flow offset

The UFB instrument operates by comparing the time taken to send an ultrasonic signal between two transducers in either direction. A Set zero flow offset adjustment is provided to compensate for any inherent differences between the two sensors, noise pick-up, internal pipe conditions etc. It can be used to 'zero' the flow indication under no-flow conditions.



Key Point: If you have adjusted the Zero Cutoff point to anywhere above '0' you must reset it to '0' before you can observe and adjust the Set zero flow offset, as its value is very small. Once the Set zero flow offset has been cancelled you can then reapply the Zero Cutoff if required.

1. Stop the liquid flow.
2. With the instrument in FLOW READING mode, press the Velocity function key and observe the reading (m/s). Any reading other than 0.000 indicates an offset error and in practice this will typically be in the range ± 0.005 m/s (possibly higher on smaller diameter pipes). If a greater figure is shown, it is worth cancelling the offset to obtain a more accurate result. Continue as follows:
3. Press the Options key to access the FLOW READING OPTION screen shown.
4. Select Set zero flow (m/s) and press ENTER.
5. Press ENTER on the subsequent screen to accept the change, which will return you to the screen shown.
6. Scroll down to select Exit and press ENTER to return to the FLOW READING screen.

FLOW READING OPTION	*	*
Data review		
Zero Cutoff (m/s)	:	0.010
Set zero flow (m/s)	:	0.000
Damping (secs)	:	10
Totalizer	:	Run
Reset +Total		



Key Point: In order to cancel any applied offset, you must read the flow via Quick Start. Any value that you trim-out using the offset adjustment will be added/ subtracted from the flow reading across the whole range.

3.3.3 Adjusting the calibration factor



Key Point: USE THIS FACILITY WITH CARE & ONLY WHERE NECESSARY

The instrument is fully calibrated before leaving the factory and under normal circumstances does not require further calibration when used on site.

This facility can be used to correct the flow indication where unavoidable errors occur due to the lack of a straight pipe or where the sensors are forced to be fitted close to the pipe-end, valve, junction etc.

Any adjustment must be made using a reference flowmeter fitted in the system.

With the system running:

1. Stop (Stall) the totalizer facility and zero it (Paragraph 3.5).
2. Run the totalizer to measure the total flow over a 30-60 minute period, and note the total flow indicated by the reference flow meter over the same period.
3. Calculate the % error between the UFB instrument and reference meters. If the error is greater than $\pm 1\%$ calibrate the UFB as detailed below.
4. Press the Options key to access the FLOW READING OPTION screen shown.
5. Scroll down and select Calibration factor then press ENTER.
6. Change the calibration factor according to the error calculated in step 3. For example, if the instrument was reading 1% high then increase the Calibration factor value by 0.010. Conversely, if the reading is 1% low then decrease the calibration factor to 0.990.
7. Press ENTER to apply the change.
8. Select Roughness factor or Exit as required and press ENTER.

FLOW READING OPTION	DD-MM-YY	HH:MM:SS
Data review		
Zero Cutoff (m/s)	:	0.010
Set zero flow (m/s)	:	0.000
Damping (secs)	:	10
Totaliser	:	Run
Reset +Total		
Reset -Total		
Calibration factor	:	1.000
Roughness factor	:	0.010
Alarm Settings	:	
Max Pulse Freq (Hz)	:	10.00
Flow at Max Frequency	:	200.00
Calculated Pulse Value:		2.00
Diagnostics		
Select Totals	:	+Total
Chiller Delay	:	0
Chiller Options	:	Off
Exit		



3.3.4 Adjusting the roughness factor

The roughness factor compensates for the condition of the internal pipe wall, as a rough surface will cause turbulence and affects the flow profile of the liquid. In most situations it is not possible to inspect the pipe internally and the true condition is not known. In these circumstances experience has shown that the following values can be used:

Pipe Material	Roughness Factor	Pipe Material	Roughness Factor
Non ferrous metal - Glass - Plastics - Light metal	0.01	Welded steel pipes, new: - Long usage, cleaned - Lightly and evenly rusted - Heavily encrusted	0.1
Drawn steel pipes: - Fine planed, polished surface. - Plane surface - Rough planed surface	0.01	Cast iron pipes: - Bitumen lining - New, without lining - Rusted / Encrusted	1.0

The increase in the roughness factor has the effect of reducing the measured flow rate, compensating for the drag caused by the rougher internal surface.

With the system running in FLOW READING mode:

1. Press the Options key to access the FLOW READING OPTION screen shown.
2. Scroll down and select Roughness factor then press ENTER.
3. Change the roughness factor according to the pipe material and condition as described above.
4. Press ENTER to apply the change.

FLOW READING OPTION	DD-MM-YY	HH:MM:SS
Data review		
Zero Cutoff (m/s)	:	0.010
Set zero flow (m/s)	:	0.000
Damping (secs)	:	10
Totaliser	:	Run
Reset +Total		
Reset -Total		
Calibration factor	:	1.000
Roughness factor	:	0.010
Alarm Settings	:	
Max Pulse Freq (Hz)	:	10.00
Flow at Max Frequency	:	200.00
Calculated Pulse Value:		2.00
Diagnostics		
Select Totals	:	+Total
Chiller Delay	:	0
Chiller Options	:	Off
Exit		

3.3.5 Adjusting the damping factor

By averaging-out the flow rate over several seconds, the Damping factor can be used to smooth out rapid changes in flow rate to prevent wild fluctuations in the displayed flow value. It has a range of 1 to 50 seconds, with a default setting of 10. With the system running in FLOW READING mode:



3: Operating Procedures

1. Press the Options key to access the FLOW READING OPTION screen shown.
2. Scroll down and select Damping (secs) and press ENTER. This will open the DAMPING OPTION screen.

FLOW READING OPTION	DD-MM-YY	HH:MM:SS
Data review		
Zero Cutoff (m/s)	:	0.010
Set zero flow (m/s)	:	0.000
Damping (secs)	:	10
Totaliser	:	Run
Reset +Total		

Reset -Total		
Calibration factor	:	1.000
Roughness factor	:	0.010
Alarm Settings	:	
Max Pulse Freq (Hz)	:	10.00
Flow at Max Frequency	:	200.00
Calculated Pulse Value:		2.00
Diagnostics		
Select Totals	:	+Total
Chiller Delay	:	0
Chiller Options	:	Off
Exit		

3. Select the value of the Damping factor as required to remove any unwanted display fluctuations. Increasing the value applies a greater smoothing affect.
4. Press ENTER to apply the change.

DAMPING OPTION	DD-MM-YY	HH:MM:SS
1 second		
10 seconds		
15 seconds		
20 seconds		
30 seconds		
50 seconds		
60 seconds		
120 seconds		
240 seconds		



Key Point: If the damping factor is set too high, the value displayed may appear stable but might exhibit large step changes when the value is updated.



3.4 Outputs

The UFB has configurable Current, Pulse, and Alarm outputs.

3.4.1 Current output

Note: Where long cable runs are necessary, or noise pickup is causing unstable flow readings, the use of two core screened cable such as BELDEN 9501 060U500, or similar, is recommended for use with the 4 to 20 mA current output. The cable screen should be connected to the RS232 GND terminal.

How to turn the 4 to 20 mA output OFF/ON

1. With the instrument operating in the FLOW READING mode, press the 4-20mA function key. This will access the 4-20mA OUTPUT screen.
2. The ON/OFF status of the 4-20mA output is shown on line 2 of the display.
3. To change the ON/OFF status select Output Range and press ENTER
4. Select Off, to turn OFF the 4-20mA Output or select one of the output ranges to turn it ON.
5. Press ENTER to return to the 4-20mA OUTPUT screen

```

4-20 mA OUTPUT          *          *
4-20 mA O/P is ON
mA Output Reading       :          0.00
Output Range            :          4-20
Units                   :          gal/min
Flow at max. output     :          0.00
Flow at min. output     :          0.00
Output mA for error     :          22.00
Exit
    
```

```

4-20 mA OUTPUT          *          *

Off
4-20mA
0-20mA
0-16mA
    
```

4 to 20 mA Signal calibration and ranging



Key Point: The 4 to 20 mA output has been calibrated in the factory and should not require further adjustment. In the rare event that re-calibration is necessary, this procedure should be carried out only by a trained engineer.

This procedure describes how to calibrate the 4 to 20 mA output and 'scale' it to cover a defined flow-rate range.

Signal calibration

6. Select Setup Instrument from the MAIN MENU then press ENTER to access the SETUP INSTRUMENT screen.
7. Select Calibrate 4-20mA. and press ENTER

```

SETUP INSTRUMENT        *          *

Set Date & Time : dd-mm-yy hh:mm:ss
Calibrate 4-20mA
Factory settings
Change Language
Exit
    
```




3: Operating Procedures

8. Connect a calibrated ammeter to the 4 to 20 mA output and adjust the UP/DOWN Scroll keys (Coarse) and LEFT/RIGHT Scroll keys 5 & 6 (fine) until the output is exactly 4.00 mA. The DAC should indicate approximately 8000.
9. Press ENTER when done.
10. With the meter still connected to the 4 to 20 mA output adjust the Scroll keys to obtain an output of exactly 20.00 mA. The DAC should indicate approximately 40000.
11. Press ENTER when done.

```
CALIBRATE 4mA          *          *  
  
Adjust the output current to 4mA  
Use Δ▽ to set, 5/6 to trim  
  
DAC Value:           8000  
  
Press ← when done
```

```
CALIBRATE 20mA         *          *  
  
Adjust the output current to 20mA  
Use Δ▽ to set, 5/6 to trim  
  
DAC Value:           40000  
  
Press ← when done
```

4-20mA Signal scaling

Note: The 4 to 20 mA can be set to represent a particular flow range. It is also possible to enter a negative figure for the minimum output and this would enable a reverse flow to be monitored.

12. With the instrument operating in the FLOW READING mode, press the 4-20mA function key. This will access the 4-20mA OUTPUT screen.
13. Select Flow at max. output and press ENTER, then enter a value of the flow rate that you want to associate with a 20.00 mA output.
14. Select Flow at min. output and press ENTER then enter a value of the flow rate that you want to associate with a 4.00 mA output. This could be '0'.

```
4-20 mA OUTPUT          *          *  
4-20 mA O/P is ON  
mA Output Reading      :      0.00  
Output Range           :      4-20  
Units                  :      gal/min  
Flow at max. output    :      0.00  
Flow at min. output    :      0.00  
Output mA for error     :      22.00
```


Exit

15. Select Output mA for error and enter a value (max of about 26 mA) that you want the 4 to 20 mA output to produce in the event of an error (e.g. if the flow-rate is outside the set range).
16. Upon completion press ENTER to return to the FLOW READING screen.



How to convert the measured current to flow rate

Assume the maximum flow rate is F_{max} (gal/min) and the minimum flow rate F_{min} is '0' (gal/min), as shown.



To calculate the flow rate (gal/min) for a measured current I (mA) then:

0-20 mA	0-16 mA	4-20 mA
Flow rate = $\frac{I \times (F_{max} - F_{min})}{20} + F_{min}$	Flow rate = $\frac{I \times (F_{max} - F_{min})}{16} + F_{min}$	Flow rate = $\frac{(I - 4) \times (F_{max} - F_{min})}{(16)} + F_{min}$

3.4.2 Pulse output

Pulse output configuration

Two parameters can be configured from the PULSE OUTPUT menu:

- Volume of fluid per pulse.
 - Pulse width.
1. With the instrument operating in the FLOW READING mode, press the Pulse function key to access the PULSE OUTPUT screen.
 2. Ensure that the Output is Off.
 3. Select Vol per pulse and press ENTER.
 4. Enter the required value. (In the example shown, a pulse is produced for every 10 gallons of flow).

```

PULSE OUTPUT          *          *
Pulse output is ON
Flow units             :          gallons
Output                 :          Off
Vol per pulse          :          10.00
Pulse width (ms)      :          10
Exit
    
```

Note: The Vol per pulse can only be changed if the Pulse Output is Off.

5. Select a Pulse width (in ms) to suit the particular application – e.g. electro-mechanical counter. Refer to the manufacturer's data sheet for the minimum pulse width.
6. Select Exit and press ENTER to return to the FLOW READING screen.



How to turn the pulse output OFF/ON

7. With the instrument operating in the FLOW READING mode, press the Pulse function key to access the PULSE OUTPUT menu.
8. Select Output and press ENTER.
9. Select On and press ENTER.
10. A *Pulse output is ON* message will appear in the second line of the display.
11. Select Exit and press ENTER to return to the FLOW READING screen.

PULSE OUTPUT	*	*
<i>Pulse output is ON</i>		
Flow units	:	gallons
Output	:	Off
Vol per pulse	:	10.00
Pulse width (ms)	:	10
Exit		

3.4.3 Alarm outputs

The UFB provides two programmable alarm outputs that are interfaced by opto-isolated relays. The relay contacts are rated at a 48 V (maximum voltage across the open contacts) and 500 mA (maximum continuous current through the closed contacts).

The two alarm outputs can be individually configured to operate in one of five modes:

- Activate at a predefined Low or High flow rate.
- Activate when a specified Volume is measured.
- Activate if a signal error is detected – either due to poor signal strength or complete signal loss.
- Alarm Test mode.
- Pulse Frequency output.

Alarm settings selection

1. To access the The ALARM SETTINGS menu select Alarm Settings from the FLOW READING OPTION menu and press ENTER.
2. The ALARM SETTINGS screen should be displayed, as shown below.
This screen shows two parameters (Mode and Limit) that can be individually set for Alarm 1 and Alarm 2.

FLOW READING OPTION	DD-MM-YY	HH:MM:SS
Data review		
Zero Cutoff (m/s)	:	0.010
Set zero flow (m/s)	:	0.000
Damping (secs)	:	10
Totaliser	:	Run
Reset +Total		
Reset -Total		
Calibration factor	:	1.000
Roughness factor	:	0.010
Alarm Settings	:	
Max Pulse Freq (Hz)	:	10.00
Flow at Max Frequency	:	200.00
Calculated Pulse Value:		2.00
Diagnostics		
Select Totals	:	+Total
Chiller Delay	:	0
Chiller Options	:	Off
Exit		



Alarm configuration

1. To setup Alarm 1, select Alarm1 Mode and press ENTER. This will access the ALARM1 MODE menu screen (shown below).

ALARM SETTINGS		*	*
Alarm1 Mode			
Alarm1 Level	:	<value>	
Alarm2 Mode			
Alarm2 Level	:	<value>	
Exit			
Alarm1 ON		Alarm2 ON	

2. Scroll down the menu to the required alarm operating mode and press ENTER.

ALARM1 MODE		*	*
Off			
Low			
High			
Volume			
On Flow Error			
Alarm Test			
Frequency			

3. This will return you to the ALARM SETTINGS menu.
4. If the selected mode is Low, High or Volume, select Alarm1 Level, enter an appropriate value then press ENTER to set the alarm operating point (see below).

ALARM SETTINGS		*	*
Alarm1 Mode			
Alarm1 Level	:	<value>	
Alarm2 Mode			
Alarm2 Level	:	<value>	
Exit			
Alarm1 ON		Alarm2 ON	

High or Low limit values

If High or Low limits are selected, the value entered in the ALARM SETTINGS menu must be in the range -9999 to +9999. This value is in the units previously selected (e.g. gal/min). The default value is +9999.

Volume limit values

If VOL limit is selected, the value entered in the ALARM SETTINGS menu must be in the range -3,999,999,999.99 to +3,999,999,999.99. This value will be in the units previous selected (e.g. liters, m3, gals) The default value should be +3,999,999,999.99.

Alarm Test

1. Select Alarm Test and press ENTER in the Alarm1 MODE menu to test that Alarm1 can be activated.
2. Select Alarm Test and press ENTER in the Alarm2 MODE menu to test that Alarm2 can be activated.

Pulse Frequency

When Frequency is selected, a variable frequency pulse proportional to the flow rate can be output at the ALARM 1 or ALARM 2 outputs. When this feature is used, the Max Pulse freq (Hz) and Flow at Max Frequency must be set in the FLOW READING OPTION menu.



Resetting an alarm

When either Alarm1 or Alarm2 is activated, the appropriate relay will be held in the closed position until:

- The activation condition is removed, or
- The Alarm is reset.

Both Alarm1 and Alarm2 can be reset by using one of the following procedure:

1. Access the The ALARM SETTINGS menu by selecting Alarm Settings from the FLOW READING OPTION menu, and press ENTER.
2. The ALARM SETTINGS screen should be displayed, as shown below.

FLOW READING OPTION	DD-MM-YY	HH:MM:SS
Data review		
Zero Cutoff (m/s)	:	0.010
Set zero flow (m/s)	:	0.000
Damping (secs)	:	10
Totaliser	:	Run
Reset +Total		
Reset -Total		
Calibration factor	:	1.000
Roughness factor	:	0.010
Alarm Settings	:	
Max Pulse Freq (Hz)	:	10.00
Flow at Max Frequency	:	200.00
Calculated Pulse Value:		2.00
Diagnostics		
Select Totals	:	+Total
Chiller Delay	:	0
Chiller Options	:	Off
Exit		

Alarm configuration

1. To reset Alarm 1, select Alarm1 Mode and press ENTER. This will access the ALARM1 MODE menu screen (shown below).

ALARM SETTINGS	*	*
Alarm1 Mode		
Alarm1 Limit	:	<value>
Alarm2 Mode		
Alarm2 Limit	:	<value>
Exit		
Alarm1 ON	Alarm2 ON	

2. Select Off from the menu and press ENTER.
3. This should de-activate the alarm.

To re-arm the alarm you must ensure that the activation condition is removed and then reconfigure the Alarm Mode as described above on page 30.

ALARM1 MODE	*	*
Off		
Low		
High		
Volume		
On Flow Error		
Alarm Test		
Frequency		



3.5 How to Measure Totalized Flows (manually)

The basic measurement indicated on the FLOW READING screen is the instantaneous flow rate, which in some applications may vary over a period of time. Average flow rates are therefore often required in order to get a better understanding of an application's true performance. This is simply achieved by noting the total flow over a specific period (for example 30-60 minutes) and then calculating the average flow rate over that period of time.

1. Press the Options key to access the FLOW READING OPTION screen shown.
2. If the Totalizer is indicating Run, select it and change it to Stall. Press ENTER.
3. Select Reset +Total and press ENTER.
4. Press ENTER on the subsequent screen to accept the reset.
5. Press ENTER again to return to the FLOW READING OPTIONS menu.
6. Select Reset -Total and press ENTER.
7. Press ENTER on the subsequent screen to accept the reset.
8. Press ENTER again to return to the FLOW READING OPTIONS menu.
9. Note and record the current time.
10. Select Totalizer and change it to Run. Press ENTER.

FLOW READING OPTION			*	*
Data review				
Zero Cutoff (m/s)	:		0.010	
Set zero flow (m/s)	:		0.000	
Damping (secs)	:		10	
Totalizer	:		Stall	
Reset +Total				

FLOW READING OPTION			*	*
Zero Cutoff (m/s)	:		0.00	
Set zero flow (m/s)	:		0.00	
Damping (secs)	:		10	
Totalizer	:		Run	
Reset +Total				
Reset -Total				

Note: the totalizers begin to count up as soon as Totalizer is set to Run.

11. Scroll down and select Exit to return to the FLOW READING screen which will now indicate the instantaneous flow together with the totalized flow.

Note that in some installations the measured flow can be in either direction. When this is the case, the upstream flow is shown separately in the -Total field.

FLOW READING			*	*
Signal			Qxx.xx%	
		12.34	gal/min	
+Total: 300.0			gallons	
-Total: 0.00			gallons	

Calculating the average flow

To calculate the average flow, wait for the allotted monitoring period to expire then divide the indicated total flow by the time taken. This will give you the average flow in m/s, galls/hour or whatever units you select.

Note that in a bi-directional flow situation you must calculate the difference between the indicated positive and negative flow totals before carrying out the average flow rate calculation.

How to stop the totalizer temporarily

If you want to stop the totalizer temporarily for operational reasons, set the Totalizer option to Stall in the FLOW READING OPTIONS screen as described above. This will stop the totalizer operation without affecting its current values.



3.6 Display of totalizers

1. To change the display of the totalizers, select the Select Totals menu item from the FLOW READING OPTION menu.
2. The display of the totals on the FLOW READING screen is controlled by this menu.
3. Select one, both or no totals to be displayed. The default is the display of the +Total.
4. Press the ENTER key.

FLOW READING OPTION

Off
Both
+Total
-Total

Note: This menu selection only affects the Display of the totalizer. Unless the totalizers are stalled, the recorded volume will still be incremented and the totals will be logged irrespective of the display setting.

3.7 Setting the Chiller Options

When there is a significant change in flow rate in a chiller system the acoustic properties of the fluid can change such that the signal is temporarily lost or a false flow reading is obtained. Under these conditions the normal action of the UFB system is to go to a fault state on both the flow reading and the current output, which may be undesirable on a short term loss of signal. This potential problem can be overcome by selecting a suitable setting in the Chiller Options sub-menu and entering an appropriate value for the Chiller Delay option, as follows.

1. Press the Options key to access the FLOW READING OPTION screen shown.
2. Scroll down and select Chiller Options and press ENTER. This will open the CHILLER OPTIONS screen.

FLOW READING OPTION DD-MM-YY HH:MM:SS

Data review		
Zero Cutoff (m/s)	:	0.010
Set zero flow (m/s)	:	0.000
Damping (secs)	:	10
Totaliser	:	Run
Reset +Total		
Reset -Total		
Calibration factor	:	1.000
Roughness factor	:	0.010
Alarm Settings	:	
Max Pulse Freq (Hz)	:	10.00
Flow at Max Frequency	:	200.00
Calculated Pulse Value:		2.00
Diagnostics		
Select Totals	:	+Total
Chiller Delay	:	0
Chiller Options	:	Off
Exit		



3. Select the required option, as detailed below.
4. Press ENTER to apply the change.

CHILLER OPTIONS	DD-MM-YY	HH:MM:SS
Off		
Zero		
Negative		
Hold		
No Reset		

Off

No change in response to a lost signal. This is the default value.

Zero

Disables the fault condition, and the system's outputs act as if the flow reading has gone to zero.

Negative

A false negative flow reading may be generated as a result of the poor conditions in the pipe; but with this option selected any negative readings are displayed as zero flow.

Hold

With this option selected, the flow reading will remain at the last valid value for a time period set by the Chiller Delay (s). After which time the normal fault condition will occur.

No Reset

Used to prevent the system changing the flow reading setup when the fluid conditions change and then, after a delay when the conditions return to normal, changing back to the original setup. This may reduce the time that the poor conditions affect the performance of the instrument, by not reacting to a short term fault condition.

3.7.1 Setting the Chiller Delay

If a signal fault occurs when the CHILLER OPTION is set to Hold, the selected Chiller Delay determines how long, in seconds, the flow reading is held at the last valid value before it reverts to a fault condition.

1. Press the Options key to access the FLOW READING OPTION screen shown.
2. Scroll down and select Chiller Delay then press ENTER.
3. Using the numerical keypad, enter a Chiller Delay value between 0 (default) and 9999 seconds.
4. Press ENTER to apply the change.
5. The applied Chiller Delay value will now be displayed.

FLOW READING OPTION	DD-MM-YY	HH:MM:SS
Data review		
Zero Cutoff (m/s)	:	0.010
Set zero flow (m/s)	:	0.000
Damping (secs)	:	10
Totaliser	:	Run
Reset +Total		
Reset -Total		
Calibration factor	:	1.000
Roughness factor	:	0.010
Alarm Settings	:	
Max Pulse Freq (Hz)	:	10.00
Flow at Max Frequency	:	200.00
Calculated Pulse Value:		2.00
Diagnostics		
Select Totals	:	+Total
Chiller Delay	:	0
Chiller Options	:	Off
Exit		



3.8 Operation with an Energy Meter

The UFB can be operated with an energy meter which allows accumulated energy measurements to be made. In this configuration, one temperature sensor is fitted to the output pipe (hot side) and another to the return pipe (cold side). The temperature difference ($\Delta T = T_{hot} - T_{cold}$), measured by the energy meter, together with the pulse input from the UFB, allows the energy meter to calculate and display the accumulated energy absorbed by the heating system.

3.8.1 Pulse output

When working with an energy meter, the UFB normal pulse output is not used. Instead, a pulse whose frequency is proportional to the flow rate is independently generated and output on ALARM1 or ALARM2 outputs. This gives a more stable reading than the pulse 'packets' that would normally be produced.

3.8.2 Configuring the UFB

Configure the UFB frequency pulse output using the following procedure:

1. From the FLOW READING screen, press the Options key to select the FLOW READING OPTIONS menu, shown here.

Note: You may need to enter the password first.
2. Scroll down to Alarm Settings and press ENTER to select the ALARM SETTINGS menu.

FLOW READING OPTION		*	*
Data review			
Zero Cutoff (m/s)	:		0.010
Set zero flow (m/s)	:		0.000
Damping (secs)	:		10
Totalizer	:		Run
Reset +Total			
Reset -Total			
Calibration factor	:		1.000
Roughness factor	:		0.010
Alarm Settings			
Max Pulse Freq (Hz)	:		10.00
Flow at Max Frequency	:		200.00
Calculated Pulse Value:			2.00
Diagnostics			
Select Totals	:		+Total
Chiller Delay	:		0
Chiller Options	:		Off
Exit			

3. Select Alarm 1 Mode and press ENTER to select the ALARM1 MODE menu shown below:

ALARM SETTINGS		*	*
Alarm1 Mode			
Alarm1 Level	:		Off
Alarm2 Mode			
Alarm2 Level	:		Off
Exit			



4. Scroll down to Frequency and press ENTER.
5. This returns to the ALARM SETTINGS menu which will indicate Frequency on the Alarm 1 Mode field as shown below.

ALARM1 MODE	*	*
Off		
Low		
High		
Volume		
On Flow Error		
Alarm Test		
Frequency		

6. Select Exit to return to the FLOW READING OPTIONS menu.

ALARM SETTINGS	*	*
Alarm1 Mode	:	Frequency
Alarm1 Level	:	
Alarm2 Mode	:	Off
Alarm2 Level	:	
Exit		

7. Scroll down to select Max Pulse Freq. (Hz) and press ENTER.
8. Enter the required maximum pulse frequency, e.g. 10Hz or 200Hz and press ENTER.
9. Select Flow at Max Frequency and press ENTER.
10. Enter the maximum flow rate (in liters per second) corresponding to 10Hz (or 200Hz) and press ENTER.
11. The Calculated Pulse Value indicates the relationship between the frequency and the flowrate. This is a non-editable value.
12. Select Exit and press ENTER to return to the FLOW READING screen. The message 'Frequency Pulse is ON' should now be displayed on the status line of the display (line 2).

FLOW READING OPTION	*	*
Data review		
Zero Cutoff (m/s)	:	0.010
Set zero flow (m/s)	:	0.000
Damping (secs)	:	10
Totalizer	:	Run
Reset +Total		
Reset -Total		
Calibration factor	:	1.000
Roughness factor	:	0.010
Alarm Settings		
Max Pulse Freq (Hz)	:	10.00
Flow at Max Frequency	:	200.00
Calculated Pulse Value:		20.0
Diagnostics		
Select Totals	:	+Total
Chiller Delay	:	0
Chiller Options	:	Off
Exit		

Note: ALARM 2 can be used instead of ALARM 1. The procedure is identical except that Alarm 2 Mode is selected and the frequency pulse output is connected to ALARM2+ and ALARM2-.



4: Maintenance & Repair

4.1 Introduction

This instrument does not contain any user-serviceable parts. The following notes are provided as a guide to general equipment



**Do not disassemble this unit.
Return the unit to an approved service agent or place of purchase for
further advice.**

4.2 General care

The following notes are provided as a guide to general equipment care.

1. Ensure the unit is disconnected from the mains, then wipe the exterior of the instrument with a clean, damp cloth or paper towel. Do not use a solvent-based cleaning fluid on the instrument as it could damage the instrument surface.
2. Ensure all cables and connectors are kept clean and free from grease or contaminants. Connectors may be cleaned with a general purpose cleaner if necessary.
3. Avoid the use of excessive grease/ultrasonic couplant on the sensors as this may impair the performance of the equipment. Excessive grease/couplant can be removed from the sensors and transducer holders using an absorbent paper towel and a general purpose solvent cleaner.
4. We recommend that the ultrasonic couplant is replaced on the sensors every 6 months, especially on pipes where the application is too hot to touch. If the signal level drops below 30% this is also an indication that the sensors need re-greasing.
5. Regularly check all cables/parts for damage. Replacement parts are available from Dwyer.
6. Ensure the person who services your instrument is qualified to do so. If in doubt, return the instrument to Dwyer with a detailed report on the nature of any problem.
7. Ensure that suitable precautions are taken when using any materials to clean the instrument/sensors.
8. If the instrument was supplied with dust or dirt caps make sure they are re-fitted when the instrument is not in use.

4.3 Warranty / Return

Refer to "Terms and Condition of Sales" in our catalog and on our website. Contact Customer Service to receive a Return Goods Authorization number before shipping the product back for repair. Be sure to include a brief description of the problem plus any additional application notes,



5: Troubleshooting

5.1 Overview

If you have a problem with your flow monitoring system it can be due to any of the following:

Faulty instrument

Blank instrument display:

- Loss of power supply to the instrument.
- Internal power supply fuse ruptured.

Scrambled instrument display:

- Reboot the instrument by temporarily disconnecting its power supply.

Incorrect setup

A low, or zero, signal could be caused by incorrect set-up such as:

- Incorrect site data entered into the instrument.
- Incorrect or non-matching ultrasonic transducers selected for use.
- Incorrectly fitted transducers – lack of couplant applied, incorrect spacing, insecure attachment.
- Poor connections between the probes and the instrument.

Application problem

If you are certain that the instrument is healthy and suitably set-up for the current site; and the probes are properly assembled and fitted correctly, there could be an application problem concerned with the site.

Check such conditions such as:

Poor pipe outer surface quality

- Uneven surface preventing good surface contact with the transducer.
- Flaking paint (should be removed).
- Variable air gap in concrete-covered pipes affecting the ultrasonic signal quality.

Poor internal pipe construction

- Rough internal pipe walls affecting fluid flow (see roughness factor).
- Internal welds positioned in the transducer signal path affecting the signal quality.
- The 'drippings' in galvanized-dipped pipes or other irregularities interfering with the signal path.

Incorrect probe location

- Transducers located too close to bends or valves, disturbing the flow profile.
- Transducers located too close to insertion probes, disturbing the flow profile.
- For horizontal pipework, transducers should not be positioned on the top of the pipe.

Poor fluid conditions within the pipe

- Fluid contains bubbles, high particle density or sludge.
- Air in the top of the pipe.

Low fluid flow within the pipe

- Pipe obstructions.
- Malfunctioning valve not opening fully (or closed inadvertently).

Liquid content problems

- Multiple liquid contents do not comply accurately to expected sound speed criteria.



- Very hot pipe almost turns water to steam and therefore exhibits the wrong speed characteristics –could be due to reduced pipe pressure.
- Flashover – liquid turns into a gas because of lower than required pressure.

5.2 General Troubleshooting Procedure




Figure 5.1 Troubleshooting chart



5.3 Warning and Status Messages

FLOW RATE ERRORS	
ERR:No flow signal	Interpretation: This message appears when the transducers cannot send or receive signals to each other. Response: Check that all cables are connected, transducers are on the pipe correctly with sufficient couplant on the face. This condition could also be due to a partially empty pipe, aerated liquid, particulate content too high or when the condition of the pipe being measured is poor.
Flow signal is poor	Interpretation: This warning appears when the signal is lower than 25%. Response: This could be due to an application problem, a poor quality pipe – see also the conditions for No flow signal (above). Check for sufficient couplant.
ERR:Zero cut-off!	Interpretation: You have entered an out-of-range value in the Zero cutoff field in the Options menu. Response: Enter a valid number.
Totalizer beyond maximum!	Interpretation: The totalizer has overflowed its maximum count. The counter will roll-over and restart from zero but this message alerts you to the fact. Response: Reset the totalizer as described in Paragraph 3.5.
PULSE ERRORS	
ERR:Pulse output!	Interpretation: The flow rate exceeds the capability of the pulse output – i.e. too many pulses per second are required than can be achieved. Response: Narrow the pulse width time or increase the volume per pulse, as described in Paragraph 3.4.2.
ERR:Pulse volume!	Interpretation: You have entered an out-of-range value in the Pulse volume error field in the PULSE OUTPUT menu – see Paragraph 3.4.2. Response: Enter a valid number.
ERR:Pulse width!	Interpretation: You have entered an out-of-range value in the Pulse width error field in the PULSE OUTPUT menu – see Paragraph 3.4.2. Response: Enter a valid number.



4-20mA ERRORS	
Calibration 20mA Error!	NOTE: The 4 to 20 mA output is calibrated before the instrument leaves the factory and should not require further adjustment. Interpretation: You have adjusted the DAC outside its accepted range when calibrating the 20 mA signal output. Response: Re-calibrate the 4 to 20 mA output – see Paragraph 3.4.1.
Calibration 4mA Error!	NOTE: The 4 to 20 mA output is calibrated before the instrument leaves the factory and should not require further adjustment. Interpretation: You have adjusted the DAC outside its accepted range when calibrating the 4 mA signal output. Response: Re-calibrate the 4 to 20 mA output – see Paragraph 3.4.1.
SET-UP ERRORS	
ERR:Pipe OD range!	Interpretation: You have entered an out-of-range value for the pipe outside diameter dimension – i.e. larger or smaller than the unit or sensor can be used on. Response: Enter a valid number.
ERR:Wall thk. range!	Interpretation: You have entered an out-of-range value for the pipe wall thickness dimension – accepted range is 0.04 to 3 inches (1 to 75 mm). Response: Enter a valid number.
ERR:Lining thick. range!	Interpretation: You have entered an out-of-range value for the lining thickness dimension – acceptable range is 0 to 1 inch (0 to 25 mm). Response: Enter a valid number.
ERR:Temperature range!	Interpretation: You have entered an out-of-range value for the fluid temperature. Accepted temperature range -4°F to +392°F (-20°C to +200°C). Response: Enter a valid number.
ERR:Invalid Date or Time!	Interpretation: The entered Date or Time is invalid, or when setting up 'timed' data logging the Stop time is set earlier than the Start time. Response: Enter a valid Date and Time.
ERR:Invalid Sensor or Mode	Interpretation: The selected temperature is higher than the maximum allowed for the sensor type. Response: Change the temperature.
Mode: Err Type	Interpretation: The selected sensors are invalid and the mode cannot be verified. Response: Choose a mode that gives a non-zero separation distance.



5.4 Diagnostics Display

This feature is designed for advanced users and is intended to provide information that will aid the user to diagnose problems – e.g. no signal strength.

When operating in the FLOW READING mode you can access a diagnostics screen by pressing the Options function key and then selecting Diagnostics from the FLOW READING OPTIONS screen. This will display the operating values for the following parameters.

Calculated time (μ s)

This is a value the instrument predicts will be the time in μ secs that it should take for the acoustic wave to propagate across a particular pipe size. This value is ascertained from the data entered by the user. i.e. Pipe size, material, sensor set etc.

Actual time (μ s)

This is the value the instrument measures as the time taken for the acoustic wave to propagate across the pipe. It is used to see if the signal is being taken from the burst, at the correct time to get the strongest signal. This value is normally a few μ s below the calculated μ s value. If, however, this value is much greater than the calculated time, there is a problem with the set-up.

Flow (m/s)

This displays flow velocity in m/s to 3 decimal places.

Signal strength

This is the averaged value of Signal and should be a value between 800 and 1600 – where 800 is approximately 50%, and 1600 is approximately 100%.

Gain

Gain values are typically in the range 600 to 850.

Switches

Typical Switches values are None and *10. On small pipes (and when using the test block) the value should be None. A Switch value of *100 indicates poor sensor set-up or poor connections.

UP/DN time difference

The difference in transit times between the upstream and downstream signals due to the fluid flow.

Fluid propagation rate

This is the sound speed of the fluid calculated using the data entered by the user.

Sensor separation

The same value as displayed in the setup screen.



6: Options

6.1 Large Pipe Diameter Transducers

Type 'D' transducers are available for use with pipe diameters in the range 59 to 197 inches (1500 to 5000 mm), operating over the temperature range -4°F to +176°F (-20°C to +80°C). The type 'D' transducer kit is supplied in a separate case and includes the sensors together with ratchet straps and transducer holders for attaching to the pipe.

6.2 Transducer Holder Options

The standard method of securing the transducer holder to the pipe is by stainless steel banding. However, optional end plates are available to allow fixing by chain.

6.3 Extended Signal Cable Options

Standard transducer cables are 16.5 ft. (5 m) in length with 33 ft. (10 m) cables being optionally available. Where, for operational reasons, it is not possible to mount the instrument this close to the sensors, bespoke cables of up to 328 ft. (100 m) can be provided. Consult Dwyer for further information and availability.



7: Specification

GENERAL	
DSP Measurement Technique:	Transit time.
Timing Resolution:	50 pico-second, continuous signal level indication on display.
Flow Velocity Range:	Minimum Velocity 0.33 ft/s; Max Velocity 33 ft/s; Bi-directional.
Turn Down Ratio:	200:1
Accuracy:	±0.5% to ±2% of flow reading for flow rates >0.66 ft/s and Pipe OD >3.0 in (75 mm). ±3% of flow reading for flow rates >0.66 ft/s and Pipe OD in range 0.5 to 3.0 in (13 to 75 mm). ±6% of flow reading for flow rates <0.66 ft/s.
Repeatability:	±0.5% of measured value or ±0.66 ft/s whichever is the greater.
Reynolds Number Correction:	Flow velocity corrected for Reynolds number over entire velocity range.
Response Time:	< 500 ms depending on pipe diameter.
Selectable Flow Units:	VELOCITY: m/sec, ft/sec. VOLUME: L/s, L/min, L/h, gal/s gal/min, gal/h, USgals/s, USgals/min, USgals/h, Barrel/h, Barrel/day, m³/s, m³/min, m³/h.
Selectable Volume Units:	US gallons, gallons, barrels (oil), liters, m³.
Total Volume:	12 Digits - forward and reverse.
APPLICABLE FLUID TYPES	
Fluid Condition:	Clean liquids or oils that have less than 3% by volume of particulate content. Applications include river water, sea water, potable water, demineralized water, glycol/water mix, hydraulic systems and diesel oil.
APPLICABLE PIPE TYPES	
Pipe Materials:	Any sonic conducting medium such as Carbon Steel, Stainless Steel, Copper, UPVC, PVDF, Concrete, Galvanized Steel, Mild Steel, Glass, Brass. Including Lined Pipes - Epoxy, Rubber, Steel, Plastic.
Pipe Dimension (outside diameter):	Min 0.5 inch (13 mm); Max 197 inches (5000 mm) with D sensor set.
Pipe Wall Thickness:	0.04 to 3.0 inches (1 to 75 mm).
Pipe Lining:	Applicable pipe linings include Rubber, Glass, Concrete, Epoxy, Steel.
Pipe Lining Thickness:	0.0 to 1.0 inches (0 to 25 mm).
Pipe Wall Temperature Range:	Standard sensor operating temperature is -4°F to +275°F (-20°C to +135°C).



7: Specification

TRANSDUCER SETS	
Standard:	Temperature Range -4°F to +275°F (-20°C to +135°C). 'A-ST' (standard) 0.5 to 4.5 inches (13 to 115 mm) pipe OD (2 MHz). 'B-ST' (standard) 2 to 79 inches (50 to 2000 mm) pipe OD (1 MHz). Protection: IP54.
Optional:	'D' 59 to 197 inch (1500 to 5000 mm) pipe OD (0.5 MHz), with an operating temperature range of -4°F to +176°F (-20°C to +80°C).
LANGUAGES	
Standard Supported Languages:	English, French, German, Italian, Spanish, Portuguese, Russian, Norwegian, Dutch, Swedish.
OUTPUTS	
Current Output: No. Channels Format: Resolution: Error Currents: Isolation: Maximum Load:	1 4 to 20 mA, 0 to 20 mA, 0 to 16 mA. 0.1% of full scale. Any between 0 to 26 mA. 1000 V Opto-isolated from unit. 620 Ohms.
Pulse Output TTL: Number Available: Isolation: Pulse Repetition Rate: Pulse Width: Max Current: Max Voltage:	1 – Opto-isolated MOSFET relay. 1500 V opto isolated from unit. User programmable from 1 to 250 pps. User programmable from 2 ms to 500 ms. 500 mA. 48 V.
Alarms: Number of Channels Available: Isolation: Relay Contact Mode: Alarm Functions: Frequency output: Max Current: Max Voltage:	2 off opto-isolated MOSFET relay. 1500 V opto isolated from unit. N/O when switching condition is False. Closed when switching condition is True. The two relays can be configured to operate when: • a predefined MINimum or MAXimum flow rate is exceeded. • a specified VOLume is measured. • a signal Error condition occurs. • manual alarm test. • pulse frequency. Maximum 200 Hz. 500 mA. 48 V.
ELECTRICAL	
Supply Voltage:	
Mains Input Voltage:	86 to 264 Vac
Mains Input Frequency:	47 to 63 Hz
Power Consumption:	10.5 W.
Alternative Input Supply:	24 V(ac/dc), 1 A max. (The 24 Vac supply must be isolated from earth.)



MECHANICAL	
Enclosure:	
Material:	ABS and aluminium.
Dimensions:	9 x 7 x 4.7 inches.
Weight:	2.65 lb.
Protection:	IP65.
Fixing:	Wall mountable.
Keypad:	
No. Keys:	15 key tactile feedback membrane keypad.
Display:	
Format:	240 x 64 pixel graphic display, high contrast black-on-white, with backlight.
Viewing Angle:	Min 30°, typically 40°.
Active Area:	5.0 in (W) x 1.3 in (H).
Overlay:	Standard English, Optional overlays available.
ENVIRONMENTAL	
Operating Temperature:	-4°F to +122°F (-20°C to +50°C).
Storage Temperature:	-13°F to +167°F (-25° to +75°C).
Operating Humidity:	90% RH MAX at +122°F.
APPROVALS	
Safety:	BS EN 61010-1:2001.
EMC:	BS EN 61326 - 1:2006, BS EN 61326-2-3:2006.
Environmental:	BS EN 60068-1:1995, BS EN 60068-2-1:2007, BS EN 60068-2-2:2007.
SHIPPING INFORMATION	
Box Dimensions:	18.9 in x 12.6 in x 6in.
Weight:	9.9 lb.
Volumetric Weight:	8.4 lb.

Dwyer reserve the right to alter any specification without notification.