User Manual

TRIPLETT

SW25 Stopwatch

CE

SW25 Stopwatch and Timer

OPERATING INSTRUCTIONS

1. Remove the plastic film on the LCD display on the front of the stopwatch
2. Slowly pull the battery protector tab out from the battery door located on the back to activate

IMPORTANT: READ THROUGH ALL INSTRUCTIONS BEFORE BEGINNING TO USE YOUR STOPWATCH

FEATURES

- Time/Calendar Display
- Hour (12/24 Hour format) minute second year month date and day
- Stopwatch Resolution: 1/100 second up to 59 minutes 1 second to 40 hours after first 40 minutes
- Tally Counter Counts up to 2999
- Electroluminescent Backlight

MAIN FUNCTION BUTTONS

A Mode Button
Switch between normal time mode stopwatch mode and tally counter mode and time setting mode

B Start/Stop Button
Used to start and stop the stopwatch function
Also for advancing digits when in time setting mode
Used to display the calendar screen
Used in combination with the Split/Reset Button to clear the tally counter

C Split/Reset Button
Used to split time in stopwatch mode
Clear timing record data stopwatch mode
Select the calendar segment to be set in time setting mode
Used to advance 1 count in tally counting mode
Used in combination with the Start/Stop Button to clear the tally counter

D Light
Used to turn on the electroluminescent backlight

DISPLAY SYMBOLS

NORMAL TIME MODE

1 Day of the Week
2 Hour
3 Minute
4 Second

CALENDAR DISPLAY

1 Day of the Week
2 Month
3 Date
4 Year

TALLY COUNTER MODE

1 Press A twice (from normal time mode) to get to tally counting mode
2 The tally counter symbol will appear on the display in the upper right hand side of the display with a "0"
3 Press either B or C to count Each press will advance the counter in values of 1
4 To clear the count press B and C simultaneously

EL BACKLIGHT

To turn on the backlight simply press the light button (D)

Note The light will remain on for about 5 seconds each time it is pressed Please note that the more the light is used the more drain it will put on the battery shortening the lifetime of the battery

CALENDAR

To see the calendar display (month/date/year) press B and hold while in normal time mode

STOPWATCH MODE/BASIC FUNCTION

Press A to until you reach Stopwatch Mode
Press B to activate the Stopwatch to count
Press C to reset the stopwatch to "0:00:00" both while using the stopwatch

1 Accumulate elapsed time measurement: B B B B C

2 Split time measurement: B C C B C

3 Measurement between two competitors: B C B C C

F we A to return to the normal time mode

TIME/CALENDAR SETTING

1. Press A three times (from normal time mode) to reach time setting mode The seconds and day of the week bar will flash to let you know you are in the setting mode
2. Press C to select the time/calendar segment to be set The sequence will be minute > hour > year > month > date > seconds (seconds will reset to 00) The day of the week will automatically be set when the year month and date are set
3. Press B to increase the setting value and change 12/24 hour format when setting the hour
4. Press A to return to the normal mode



BATTERY REPLACEMENT

When the LCD becomes dim replace with a new type CR2032 3 Volt battery

To replace battery open battery compartment door with a coin and remove the door Replace with a fresh CR2032 battery making sure to observe the correct polarity Replace the battery compartment door and closely by twisting into place with a coin The triangle on the battery door should align with the triangle on the self frame at the top to ensure the battery door is properly closed

CAUTION Battery Safety Information

- Non rechargeable batteries are not to be recharged
- Rechargeable batteries must be removed before recharging
- Rechargeable batteries only to be charged under adult supervision
- Do not mix alkaline standard (carbon zinc) or rechargeable nickel cadmium batteries
- Do not mix old and new batteries
- Exhausted batteries to be removed
- Do not dispose of battery in fire Battery may explode or leak
- Do not dispose of adult in fire Battery may explode or leak