

#30-682SM #30-682SF

PowerPlug™ Disconnect - Model 182S Installation Instructions:



Instructions:

Conductor installation:

- 1. Wiring must comply with all applicable electrical codes.
- 2. Turn off power before removing or installing disconnect.
- 3. Strip wires to 3/8 inch (9,5 mm).
- 4. Grip wire firmly and push conductor while twisting the connector back and forth into port marked #1 on male connector half.
- 5. Repeat step 4 for port #2.
- 6. Repeat steps 4 and 5 for female connector half.
- 7. Use only one conductor per port and assure that no copper is exposed on any of the wires inserted.
- See disconnect de-mate/mate installation instructions on this page when disconnecting the connector.
- The wire insertion side of this product is listed for ONE TIME USE ONLY. DO NOT REMOVE AND REPLACE WIRES.

TABLE 1: Voltage/Current Maximum

Voltage (V)	Current (A)
600	3

TABLE 2: Wire Size & Type

Wire Type	Wire Size
Solid	18-22 AWG
Stranded	18 AWG (16 strand or less)
Tin Bonded	18-22 AWG (16 strand or less)
Copper to copper connections only. Do not use on Aluminum.	

TABLE 3: Environmental Conditions

Environmental Conditions	Rating
Temperature Rating	105°C (221°F)
Flame Rating	UL94V-0

Disconnect de-mate / mate installation

- To de-mate, grasp disconnect at each end and pull apart to separate the disconnect halves. Do NOT pull on wires.
- 2. To mate the disconnect, grasp each disconnect half, align halves, and push together.
- 3. Completed connection should appear as shown.



