

Dial Test Indicators 3808, 3809, 3908 & 3909 Series

These dial test indicators are offered with choices of dial size, range and include accessories.

All 3808 and 3809 models have 1-1/4" (32mm) dial faces while 3908 and 3909 models offer a larger 1-9/16" (40mm) dial face.

Each inch reading and metric reading 3808, 3809, 3908 and 3909 is offered with a choice of two Graduation/Range/Reading configurations.

Features & Specifications

- Three dovetail positioning mounts work with most existing test indicator accessories
- · Precision gear-driven design with smooth, jeweled movement
- Contact point reverses automatically, always maintaining clockwise hand rotation
- · Frictionally adjustable contacts
- Meets or exceeds ANSI/ASME accuracy specifications
- High contrast, easy-to-read dials with white background for inch and yellow for metric
- · Satin chrome finish



3808, 3809, 3908 & 3909 Inch Reading Indicators										
Grad	Range	Dial Reading	Dial Diameter	Description	Cat. No.	EDP				
.0001"	.008"	0-4-0	1-1/4"	Indicator, two dovetail clamps, case*	3808A	12331				
				Indicator with accessories, case**	3808AC	12303				
			1-9/16"	Indicator, two dovetail clamps, case*	3908A	12488				
				Indicator with accessories, case**	3908AC	12636				
.0005"	.030"	0-15-0	1-1/4"	Indicator, two dovetail clamps, case*	3809A	12333				
				Indicator with accessories, case**	3809AC	12305				
			1-9/16"	Indicator, two dovetail clamps, case*	3909A	12527				
				Indicator with accessories, case**	3909AC	12669				

 $^{^{\}star}\,$ Indicator, .156" contact point, 3/8" & 5/32" dovetail clamps & case

^{**} Indicator, .078" & .156" contact points, 3/8" & 5/32" dovetail clamps, .156" swivel post holder, tool post holder, contact wrench & case

3808, 3809, 3908 & 3909 Metric Reading Indicators									
Grad	Range	Dial Reading	Dial Diameter	Description	Cat. No.	EDP			
0.002mm	0.2mm	0-100-0	32mm	Indicator, two dovetail clamps, case*	3808MA	12332			
				Indicator with accessories, case**	3808MAC	12304			
			40mm	Indicator, two dovetail clamps, case*	3908MA	12520			
				Indicator with accessories, case**	3908MAC	12656			
0.01mm	0.8mm	0-40-0	32mm	Indicator, two dovetail clamps, case*	3809MA	12334			
				Indicator with accessories, case**	3809MAC	12307			
			40mm	Indicator, two dovetail clamps, case*	3909MA	12563			
				Indicator with accessories, case**	3909MAC	12673			

^{*} Indicator, 4mm contact point, 9.5mm & 4mm dovetail clamps & case



AC & MAC indicators include two contact points,

two dovetail clamps, swivel post holder, tool post holder, contact wrench and case

A & MA indicators include two dovetail clamps and case





^{**} Indicator, 2mm & 4mm contact points, 9.5mm & 4mm dovetail clamps, 4mm swivel post holder, tool post holder, contact wrench & case