

EL-MOTE



Quick Start Guide



Welcome! Let's set up your EL-MOTE

Before you connect your EL-MOTE, you need to do a few things.

- You'll need to set up an account on so that you can view your devices remotely.
- Download the EasyLog Cloud App on your phone or tablet
- Have your WiFi network details to hand


Not an Apple or Android user? Visit the support section on www.easylogcloud.com for alternative set up methods.
























View and change device settings using the App or at


Device Indication Overview

State		Front Button LED	Sounder
/	Device OK	1 Flash / 5 Sec	No Sounder
X	Fault	1 Flash / 5 Sec	Single tone ring every 30 minutes
	Alarm	1 Flash / 5 Sec	Continuous two tone ring

visual / sound state indication guide.







Important Safety Information

WARNING: Failure to follow these safety instructions could result in fire, electrical shock, other injury or damage.

Repairing or modifying

Never attempt to repair or modify this product. Dismantling may cause damage that is not covered under the warranty. Servicing should only be provided by an approved supplier. If the product has been punctured or seriously damaged, do not use it and return it to an approved supplier.

Using connectors and ports

Never force a connector into a port. Check for obstruction in the port; make sure that the connector matches the port and that you have positioned the connector correctly in relation to the port. If the connector and port do not join with reasonable ease, they probably do not match and should not be used.

Power supply

Only use 1.5V AA batteries or a genuine EL-MOTE power adapter to power your EL-MOTE data logger.

Disposal and recycling

You must dispose of this product and batteries according to relevant laws and regulations. This product contains electronic components and therefore must be disposed of separately from household waste.

Caution:

Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

