ON DIST



ON DIST 2 sec.



2 sec.



2 sec.



FUNC 2 sec.

Settings

FUNC 2 sec. 1.1 UNIT 0.000 m / 0.0000 m / 0.000 in → 0.00 ft / 0'00" 1/32 / 0 in 1/32

FUNC / ON DIST → 2.1 BEEP ON → OFF

FUNC / ON DIST → 3.1 TILT CAL

+ − Change settings in submenu / turn function ON/OFF

FUNC 2 sec. Exit

C Exit

2 sec.

Bluetooth / NFC

2 sec. 1.1 BLUET

/ ON DIST → 2.1 NFC

Transfer value from main line

2 sec. Exit

+ − Turn function ON/OFF

C Exit

1...30 8.294 m

Memory

Navigate through last 30 values

+ −

Clear memory:

C + 2 sec.



Quick Start

Leica DISTO™ D2/D2G

1 Display
2 ON/Measure
3 Add
4 Clear/OFF
5 Memory/Timer
6 Measuring Reference
7 Bluetooth/ NFC
8 Functions/ Settings
9 Subtract

- when it has to be right

Leica Geosystems

1.800.561.8187 www.itm.com information@itm.com

2 sec.

Timer

Adjust delay of automatic release

+ −

FUNC 2x

Volume



FUNC 2 sec.

FUNC 4x

Smart Horizontal



FUNC 6x

Stake-out



User Manual:

FUNC 1x

Area



FUNC 3x

Triangle Area



FUNC 2 sec.

FUNC 5x

Pythagoras (3-point)



FUNC 7x

Levelling



ON DIST → ON

C → OFF

2 sec.