

User Manual



# TLT10 Telephone Line Tester



## Introduction

The Triplet TLT10 Telephone Line Tester checks the status of single and dual phone lines. When plugged into a phone jack, two tri-color LEDs indicate if the lines are active and wired properly. With proper use, this tester will provide many years of reliable service.

### ⚠ WARNINGS

- Read, understand and follow Safety Rules and Operating Instructions in this manual before using this tester.
- Use caution when checking electrical circuits. Comply with all safety codes.
- Do not modify or try to repair the tester. No serviceable parts are inside.
- Do not use this tester in wet or damp environments or during electrical storms.
- Do not use this tester near explosive vapors, dust or gasses.
- Do not use this tester if it appears damaged or operates incorrectly.

### General Specifications

|                       |   |
|-----------------------|---|
| Operating temperature | 14°F to 122°F (-10°C to 50°C)                         |
| Storage temperature   | -4°F to 140°F (-20°C to 60°C)                         |
| Dimensions            | 3.11 in. x 0.91 in. x 0.63 in (7.9cm x 2.3cm x 1.6cm) |
| Weight                | 0.49 oz (13.8g)                                       |



## Tester Description

---



1. Line 1 LED Indicator
2. Line 2 LED Indicator
3. RJ11 Plug

## Operation

---

1. Plug the tester into an RJ11 phone jack
  2. Observe the LED indicators. See the chart below to determine status.
- Note** that only one LED will illuminate if the jack is wired for a single line.

| LED      | Status  |
|----------|---|
| Green    | Line is wired properly  |
| Red      | Line is reverse wired   |
| Yellow   | AC voltage is on the line<br>(Flashing yellow indicates ring voltage) |
| No Light | Line is dead  |

## Warranty

---

Triplett / Jewell Instruments extends the following warranty to the original purchaser of these goods for use. Triplett warrants to the original purchaser for use that the products sold by it will be free from defects in workmanship and material for a period of (1) one year from the date of purchase. This warranty does not apply to any of our products which have been repaired or altered by unauthorized persons in any way or purchased from unauthorized distributors so as, in our sole judgment, to injure their stability or reliability, or which have been subject to misuse, abuse, misapplication, negligence, accident or which have had the serial numbers altered, defaced, or removed. Accessories, including batteries are not covered by this warranty

Copyright © 2022